



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT				
------	------------	-------	----------------	---	-------------	--	--	--	--

CHEVROLET/GMC

Chevrolet/GMC SUVs

1969-1991	JIMMY/BLAZER (4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1973-1991	JIMMY/BLAZER (2WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001

Chevrolet/GMC Pickup Trucks

2004-2012	COLORADO/CANYON (2WD/4WD)	HP10224 ◇	L6383	SS	Inside	No	2 Hrs	HP10001
2009-2012	COLORADO/CANYON (2WD/4WD)	HP10226 ◇	L6383	SS	Inside	No	2 Hrs	HP10173
2015-2022	COLORADO/CANYON (2WD/4WD) <i>Will not fit ZR2 or AT4 models</i>	HP10339	L6483	SS	Inside	No	2 Hrs	HP10199

Chevrolet Silverado/GMC Sierra 1500

1973-1987	C-10 (2WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1973-1987	C-10 (2WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1973-1987	K-10 (4WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1973-1987	K-10 (4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1988-1998	SIERRA/SILVERADO K/C 1500 (2WD/4WD)	HP10088 *** / Δ HP10120 *** / Δ	L5932	DC SC	Inside	Yes	3 Hrs	HP10000 HP10083
2001-2006	SIERRA/SILVERADO 1500HD (2WD/4WD) HEAVY LOADS	HP10072 ****	L5863	DC	Inside	No	2½ Hrs	HP10000
1999-2007	SIERRA/SILVERADO 1500 (2WD/4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
2001-2005	SILVERADO 1500HD (2WD/4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
2001-2008	SIERRA 1500HD (2WD/4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
2007-2018	SIERRA/SILVERADO 1500 (2WD/4WD) FOR SHORT (69.3") AND MEDIUM (78.7") TRUCK BED LENGTHS <i>Will not fit if vehicle is equipped with MagneRide</i>	HP10216	L6360	DC	Inside	No ♦	3 Hrs	HP10000
2007-2018	SIERRA/SILVERADO 1500 (2WD/4WD) FOR SHORT (69.3") AND MEDIUM (78.7") TRUCK BED LENGTHS	HP10144	L6035	SS	Outside	No	2 Hrs	HP10001
2007-2018	SIERRA/SILVERADO 1500 (2WD/4WD) FOR LONG (97.8") TRUCK BED LENGTHS	HP10178	L6035	SS	Outside	No	2 Hrs	HP10001
2019	SIERRA LIMITED/SILVERADO LD 1500 (2WD/4WD)	HP10216	L6360	DC	Inside	No ♦	3 Hrs	HP10000
2019-2024	SIERRA/SILVERADO 1500 (2WD/4WD) FOR ALL TRUCK BED LENGTHS. <i>AT4/Trail Boss - requires use of 2" spacer 10152. Will not fit if vehicle is equipped with Adaptive Ride Control.</i>	HP10340	L6453	DC	Inside	No ♦	2 Hrs	HP10000

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

REPLACEMENT AIR SPRING	AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
VEHICLE MODIFICATION REQUIRED	SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
* 10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME	†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)			
** WILL ONLY FIT WITH STOCK WHEELS AND TIRES	††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH			
FOR 'C' CHANNEL FRAMES	†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS			
*** FOR HYDRO FORMED FRAMES	‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES			
▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION	‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES			
✕ VEHICLE MUST HAVE A LIFT BLOCK	♦	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH			
Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120	♦♦	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS			
	▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS			



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230

26688 56 Ave, Langley, BC V4W 3X5

800.663.0096 / pacbrake.com

EMAIL info@pacbrake.com

FAX 604.882.2330



REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
CHEVROLET/GMC								
Chevrolet Silverado/GMC Sierra 2500								
1973-1987	C-20 (2WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1973-1987	C-20 (2WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1973-1987	K-20 (4WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1988-1998	SIERRA/SILVERADO K/C 2500 (2WD/4WD)	HP10088 *** / Δ HP10120 *** / Δ	L5932	DC SC	Inside	Yes	3 Hrs	HP10000 HP10083
1999-2000	SIERRA/SILVERADO 2500 (2WD/4WD) DRUM BRAKES ONLY	HP10088 *** / Δ HP10120 *** / Δ	L5932	DC SC	Inside	Yes	3 Hrs	HP10000 HP10083
2001-2010	SIERRA/SILVERADO 2500HD (2WD/4WD)	HP10005 †††	L5683	DC	Inside	No	2 Hrs	HP10000
2011-2019	SIERRA/SILVERADO 2500HD (2WD/4WD)	HP10171 †††	L6135	DC	Inside	No ♦	2½ Hrs	HP10000
2011-2019	SIERRA/SILVERADO 2500HD (2WD/4WD) RATED UP TO 7500lbs	HP10171-X †††	L6518	DC	Inside	No ♦	2½ Hrs	HP10438
2020-2021	SIERRA/SILVERADO 2500HD (2WD/4WD)	HP10355 †††	L6502	DC	Inside	No	2½ Hrs	HP10000
2020-2021	SIERRA/SILVERADO 2500HD (2WD/4WD) RATED UP TO 7500lbs	HP10355-X †††	L6504	DC	Inside	No	2½ Hrs	HP10438
2022-2024	SIERRA/SILVERADO 2500HD (2WD/4WD) Will not fit vehicles equipped with Curt 5th wheel packages	HP10585 †††	L6575	DC	Inside	No	2½ Hrs	HP10000
2022-2024	SIERRA/SILVERADO 2500HD (2WD/4WD) Will not fit vehicles equipped with Curt 5th wheel packages RATED UP TO 7500lbs	HP10585-X †††	L6575	DC	Inside	No	2½ Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

REPLACEMENT AIR SPRING	AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
VEHICLE MODIFICATION REQUIRED	SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
* 10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME	†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)			
** WILL ONLY FIT WITH STOCK WHEELS AND TIRES	††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH			
*** FOR 'C' CHANNEL FRAMES	†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS			
**** FOR HYDRO FORMED FRAMES	‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES			
▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION	‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES			
✕ VEHICLE MUST HAVE A LIFT BLOCK	♦	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH			
Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120	◆	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS			
	▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS			



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230 • 800.663.0096 / pacbrake.com

26688 56 Ave, Langley, BC V4W 3X5 • EMAIL info@pacbrake.com • FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT				
------	------------	-------	----------------	---	-------------	--	--	--	--

CHEVROLET/GMC

Chevrolet Silverado/GMC Sierra 3500

1973-1987	C-30 (2WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1973-1987	C-30 (2WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1973-1987	K-30 (4WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1988-2000	SIERRA/SILVERADO K/C 3500 (2WD/4WD)	HP10088 *** / Δ HP10120 *** / Δ	L5932	DC SC	Inside	Yes	3 Hrs	HP10000 HP10083
2001-2010	SIERRA/SILVERADO 3500HD (2WD/4WD) <i>Will not fit commercial cab & chassis</i>	HP10005	L5683	DC	Inside	No	2 Hrs	HP10000
2001-2010	SIERRA/SILVERADO 3500HD (2WD/4WD) <i>RATED UP TO 7500Lbs</i>	HP10005-X †††	L6519	DC	Inside	No	2 Hrs	HP10438
2011-2019	SIERRA/SILVERADO 3500HD (2WD/4WD)	HP10171 †††	L6135	DC	Inside	No ♦	2½ Hrs	HP10000
2011-2019	SIERRA/SILVERADO 3500HD (2WD/4WD) <i>RATED UP TO 7500Lbs</i>	HP10171-X †††	L6518	DC	Inside	No ♦	2½ Hrs	HP10438
2020-2021	SIERRA/SILVERADO 3500HD (2WD/4WD)	HP10355 †††	L6502	DC	Inside	No	2½ Hrs	HP10000
2020-2021	SIERRA/SILVERADO 3500HD (2WD/4WD) <i>RATED UP TO 7500Lbs</i>	HP10355-X †††	L6504	DC	Inside	No	2½ Hrs	HP10438
2022-2024	SIERRA/SILVERADO 3500HD (2WD/4WD) <i>Will not fit vehicles equipped with Curt 5th wheel packages</i>	HP10585 †††	L6575	DC	Inside	No	2½ Hrs	HP10000
2022-2024	SIERRA/SILVERADO 3500HD (2WD/4WD) <i>Will not fit vehicles equipped with Curt 5th wheel packages RATED UP TO 7500Lbs</i>	HP10585-X †††	L6575	DC	Inside	No	2½ Hrs	HP10438

Chevrolet/GMC Motorhomes (Class C Vans) & Commercial Vehicles

2013-2015	CLASS C MOTORHOME G3500 (2WD) DRW VEHICLES	HP10227	L6386	SC	Inside	No	2 Hrs	HP10083
2013-2015	CLASS C MOTORHOME G4500 (2WD) DRW VEHICLES	HP10227	L6386	SC	Inside	No	2 Hrs	HP10083
2018-2024	SILVERADO 4500HD (2WD/4WD) CAB & CHASSIS <i>RATED UP TO 7500Lbs</i>	HP10373-X	L6517	DC	Inside	Yes	2½ Hrs	HP10438
2018-2024	SILVERADO 5500HD (2WD/4WD) CAB & CHASSIS <i>RATED UP TO 7500Lbs</i>	HP10373-X	L6517	DC	Inside	Yes	2½ Hrs	HP10438
2018-2024	INTERNATIONAL CV CLASS 4 / 5 TRUCKS <i>RATED UP TO 7500Lbs</i>	HP10373-X	L6517	DC	Inside	Yes	2½ Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

REPLACEMENT AIR SPRING	AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
VEHICLE MODIFICATION REQUIRED	SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
* 10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME	†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)			
** WILL ONLY FIT WITH STOCK WHEELS AND TIRES	††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH			
*** FOR 'C' CHANNEL FRAMES	†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS			
**** FOR HYDRO FORMED FRAMES	‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES			
▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION	‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES			
✕ VEHICLE MUST HAVE A LIFT BLOCK	♦	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH			
Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120	◆	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS			
	▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS			



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230

26688 56 Ave, Langley, BC V4W 3X5

800.663.0096 / pacbrake.com

EMAIL info@pacbrake.com

FAX 604.882.2330



REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
------	------------	-------	----------------	---	-------------	--	--	--

DODGE/RAM

Dodge SUVs

1974-1993	RAM CHARGER (2WD/4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
-----------	-----------------------	-----------	-------	----	---------	-----	--------	---------

Dodge Pickup Trucks

1987-2004	DAKOTA (4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
2005-2011	DAKOTA (2WD/4WD)	HP10220 ◇	L6370	SS	Outside	Yes	2½ Hrs	HP10001
2000-2001	DAKOTA RT (2WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1969-1993	W-100 (2WD/4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1969-1993	W-100 (2WD/4WD) HEAVY LOADS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1969-1993	D-150, W-150 (2WD/4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1969-1993	D-150, W-150 (2WD/4WD) HEAVY LOADS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1969-1993	D-250, W-250 (2WD/4WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1969-1993	D-350, W-350 (2WD/4WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000

Ram 1500

1994-2001	RAM 1500 (2WD/4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1994-2001	RAM 1500 (2WD) HEAVY LOADS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
2002-2008	RAM 1500 (2WD/4WD) HEAVY LOADS	HP10071	L5835	DC	Inside	No	2½ Hrs	HP10000
2009-2024	RAM 1500 (2WD/4WD) <i>Will not fit TRX models</i>	HP10337 ▪	L6480	SC	Inside	No	2 Hrs	HP10083
2019-2023	RAM 1500 CLASSIC (2WD/4WD) <i>Will not fit TRX models</i>	HP10337 ▪	L6480	SC	Inside	No	2 Hrs	HP10083
2009-2023	RAM 1500 CLASSIC (2WD/4WD) <i>Will not fit TRX models</i>	HP10567 ▪	L6576	IC	Inside	No	1 Hr	HP10560
2006-2008	RAM 1500 MEGA CAB (4WD)	HP10002 ‡	L5682	DC	Inside	No	2 Hrs	HP10000
2006-2008	RAM 1500 MEGA CAB (2WD)	HP10089 ‡‡	L5682	SC	Inside	No	2 Hrs	HP10083

Ram 2500

1994-2002	RAM 2500 (2WD/4WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
2003-2013	RAM 2500 (4WD) INCLUDING MEGA CAB	HP10002 ‡	L5682	DC	Inside	No	2 Hrs	HP10000
2013	RAM 2500 (4WD) INCLUDING MEGA CAB <i>RATED UP TO 7500lbs</i>	HP10002-X ‡	L6520	DC	Inside	No	2 Hrs	HP10438
2003-2013	RAM 2500 (2WD) INCLUDING MEGA CAB	HP10089 ‡‡	L5682	SC	Inside	No	2 Hrs	HP10083
2014-2024	RAM 2500 (2WD/4WD) <i>Will not fit with factory optional air equipped</i>	HP10206	L6345	DC	Inside	No	2 Hrs	HP10000
2014-2024	RAM 2500 (2WD/4WD) <i>Will not fit with factory optional air equipped RATED UP TO 7500lbs</i>	HP10206-X	L6521	DC	Inside	No	2 Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

REPLACEMENT AIR SPRING	AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
VEHICLE MODIFICATION REQUIRED	SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
* 10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME		†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
** WILL ONLY FIT WITH STOCK WHEELS AND TIRES		††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
*** FOR 'C' CHANNEL FRAMES		†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
**** FOR HYDRO FORMED FRAMES		‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION		‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
✕ VEHICLE MUST HAVE A LIFT BLOCK		◆	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120		◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
		▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230 • 800.663.0096 / pacbrake.com

26688 56 Ave, Langley, BC V4W 3X5 • EMAIL info@pacbrake.com • FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
DODGE/RAM								
Ram 3500								
1994-2002	RAM 3500 (2WD/4WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
2003-2018	RAM 3500 (4WD) INCLUDING MEGA CAB	HP10002 ‡	L5682	DC	Inside	No	2 Hrs	HP10000
2013-2018	RAM 3500 (4WD) INCLUDING MEGA CAB <small>RATED UP TO 7500LBS</small>	HP10002-X ‡	L6520	DC	Inside	No	2 Hrs	HP10438
2003-2018	RAM 3500 (2WD) INCLUDING MEGA CAB	HP10089 ††	L5682	SC	Inside	No	2 Hrs	HP10083
2019-2024	RAM 3500 (2WD/4WD) <small>Will not fit with factory optional air equipped or cab & chassis models.</small>	HP10368	L6512	DC	Inside	No	2½ Hrs	HP10000
2019-2024	RAM 3500 (2WD/4WD) <small>RATED UP TO 7500LBS</small> <small>Will not fit with factory optional air equipped or cab & chassis models.</small>	HP10368-X	L6512	DC	Inside	No	2½ Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

REPLACEMENT AIR SPRING	AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
VEHICLE MODIFICATION REQUIRED	SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
* 10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME	†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)			
** WILL ONLY FIT WITH STOCK WHEELS AND TIRES	††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH			
*** FOR 'C' CHANNEL FRAMES	†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS			
**** FOR HYDRO FORMED FRAMES	‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES			
▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION	‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES			
✕ VEHICLE MUST HAVE A LIFT BLOCK	◆	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH			
Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120	◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS			
	▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS			



PACBRAKE

USA

1670 Grant Ave, Blaine, WA 98230

800.663.0096 / pacbrake.com



CANADA

26688 56 Ave, Langley, BC V4W 3X5

EMAIL info@pacbrake.com

FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
DODGE/RAM								
Dodge Vans/Commercial Vehicles								
2013-2024	RAM ProMaster 1500 (2WD/4WD)	HP10365	L6511	SC	Inside	No	2 Hrs	HP10083
2013-2024	RAM ProMaster 2500 (2WD/4WD)	HP10365	L6511	SC	Inside	No	2 Hrs	HP10083
2013-2024	RAM ProMaster 3500 (2WD/4WD)	HP10365	L6511	SC	Inside	No	2 Hrs	HP10083
2006-2018	RAM 3500 (2WD/4WD) CAB & CHASSIS <i>The 10136 must be purchased for vehicles that have a round axle tube with the breather located approximately 7" from the spring pack.</i>	HP10002 ‡ & HP10136	L5682	DC	Inside	No	2 Hrs	HP10000
2019-2020	RAM 3500 (2WD/4WD) CAB & CHASSIS <i>The 10349 must be purchased for vehicles that have a round axle tube with the breather located approximately 7" from the spring pack.</i>	HP10002 ‡ & HP10349	L5682	DC	Inside	No	2 Hrs	HP10000
2007-2009	RAM 4500 (2WD/4WD) CAB & CHASSIS	HP10121	L5934	DC	Inside	No	3 Hrs	HP10068
2018-2024	RAM 4500 (2WD/4WD) CAB & CHASSIS <i>RATED UP TO 7500lbs</i>	HP10371-X	L6516	DC	Inside	Yes	2½ Hrs	HP10438
2010-2020	RAM 4500 (2WD/4WD) CAB & CHASSIS	HP10321	L6454	DC	Inside	No	2 Hrs	HP10068
2007-2009	RAM 5500 (2WD/4WD) CAB & CHASSIS	HP10121	L5934	DC	Inside	No	3 Hrs	HP10068
2010-2020	RAM 5500 (2WD/4WD) CAB & CHASSIS	HP10321	L6454	DC	Inside	No	2 Hrs	HP10068
2018-2024	RAM 5500 (2WD/4WD) CAB & CHASSIS <i>RATED UP TO 7500lbs</i>	HP10371-X	L6516	DC	Inside	Yes	2½ Hrs	HP10438
2007-2009	SPRINTER 2500 (2WD)	HP10147	L6037	DC	Inside	Yes	2½ Hrs	HP10000
2007-2024	SPRINTER 2500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10395 ▼	L6536	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 2500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models RATED UP TO 7500lbs</i>	HP10395-X ▼	L6536	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 3500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10395 ▼	L6536	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 3500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models RATED UP TO 7500lbs</i>	HP10395-X ▼	L6536	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 3500XD (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10391 ▼	L6527	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 3500XD (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models RATED UP TO 7500lbs</i>	HP10391-X ▼	L6527	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 4500 (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10391 ▼	L6527	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 4500 (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models RATED UP TO 7500lbs</i>	HP10391-X ▼	L6527	DC	Inside	No	2 Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

REPLACEMENT AIR SPRING	AIR SPRING STYLE	DC DOUBLE CONVOLUTED	SS SLEEVE STYLE
VEHICLE MODIFICATION REQUIRED	SUGGESTED INSTALLATION TIME	SC SINGLE CONVOLUTED	IC IN-COIL
* 10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME	† 10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
** WILL ONLY FIT WITH STOCK WHEELS AND TIRES	†† 10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
*** FOR 'C' CHANNEL FRAMES	††† FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
**** FOR HYDRO FORMED FRAMES	‡ 10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION	‡‡ 10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
✕ VEHICLE MUST HAVE A LIFT BLOCK	♦ DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120	◆ SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
	▼ WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230

26688 56 Ave, Langley, BC V4W 3X5

800.663.0096 / pacbrake.com

EMAIL info@pacbrake.com

FAX 604.882.2330



REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
------	------------	-------	----------------	---	-------------	--	--	--

FORD

Ford SUVs

1980-1996	BRONCO (4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1983-1990	BRONCO II (4WD)	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001

Ford Pickup Trucks

1998-2010	RANGER (2WD/4WD)	HP10019 **/†	L5685	DC	Outside	Yes	3 Hrs	HP10000
2019+	RANGER (2WD/4WD) EXCLUDES TREMOR	HP10352	L6491	SS	Outside	No	2 Hrs	HP10199
1966-1996	F-100 (4WD) HEAVY LOADS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1966-1996	F-100 (4WD) LIGHT LOADS	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1968-1996	F-100 (2WD) HEAVY LOADS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1968-1996	F-100 (2WD) LIGHT LOADS	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001

Ford F-150

1966-1996	F-150 (4WD) HEAVY LOADS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1968-1996	F-150 (2WD) HEAVY LOADS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1968-1996	F-150 (2WD) LIGHT LOADS	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
1997-2003	F-150 (2WD/4WD) INCLUDING HERITAGE	HP10033 *	L6030	SS	Outside	Yes	2½ Hrs	HP10001
2004-2008	F-150 (2WD/4WD) HEAVY LOADS <i>Will not fit FX2</i>	HP10004	L5681	DC	Outside	No	2 Hrs	HP10000
2004-2009	F-150 (2WD/4WD) EXCLUDES HERITAGE	HP10153	L6146	SS	Outside	No	2½ Hrs	HP10173
2010-2014	F-150 (2WD/4WD) EXCLUDES HERITAGE & F-150 RAPTOR <i>Will not fit newer style, aluminum body trucks</i>	HP10155	L6146	SS	Outside	No	2½ Hrs	HP10001
2004-2014	F-150 (4WD) EXCLUDES RAPTOR	HP10212	L6335	DC	Inside	No	2½ Hrs	HP10000
2004-2014	F-150 (2WD) EXCLUDES RAPTOR	HP10605	L6335	SC	Inside	No	2½ Hrs	HP10083
2015-2020	F-150 (4WD) EXCLUDES RAPTOR	HP10358	L6497	DC	Outside	No	1½ Hrs	HP10000
2021-2024	F-150 (2WD~ / 4WD) INCLUDING POWER BOOST EXCLUDES RAPTOR & LIGHTNING <i>*2WD applications require use of 2" spacer 10152. Vehicles equipped with CCD (continuously controlled dampening) require additional passenger side rear height sensor relocation brackets 10402-RH.</i>	HP10402	L6539	DC	Outside	No	2 Hrs	HP10000

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

REPLACEMENT AIR SPRING	AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
VEHICLE MODIFICATION REQUIRED	SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
* 10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME		†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
** WILL ONLY FIT WITH STOCK WHEELS AND TIRES		††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
*** FOR 'C' CHANNEL FRAMES		†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
**** FOR HYDRO FORMED FRAMES		‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION		‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
✕ VEHICLE MUST HAVE A LIFT BLOCK		◆	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120		◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
		▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230 • 800.663.0096 / pacbrake.com

26688 56 Ave, Langley, BC V4W 3X5 • EMAIL info@pacbrake.com • FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
FORD								
Ford F-250								
1969-1979	F-250 (2WD) UNDER 7500 GVWR	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1980-1996	F-250 (2WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1980-1997	F-250 (4WD) '97 HEAVY DUTY OVER 8600 GVWR	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1997-1998	F-250 LIGHT DUTY (2WD/4WD) UNDER 7500 GVWR	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1999-2010	F-250 SUPER DUTY (2WD/4WD)	HP10070 ††	L5754	DC	Outside	Yes	3 Hrs	HP10000
2005-2010	F-250 SUPER DUTY (2WD)	HP10182 †††	L6220	DC	Inside	No ♦	4 Hrs	HP10000
2005-2010	F-250 SUPER DUTY (4WD)	HP10181 †††	L6220	DC	Inside	No ♦	4 Hrs	HP10000
2010-2016	F-250 SUPER DUTY (2WD/4WD) <i>Will not fit vehicles with factory installed 5th wheel hitch</i>	HP10070 ††	L5754	DC	Outside	Yes	3 Hrs	HP10000
2011-2016	F-250 SUPER DUTY (2WD)	HP10194 †††	L6219	DC	Inside	No ♦	4 Hrs	HP10000
2011-2016	F-250 SUPER DUTY (2WD/4WD)	HP10387 †††	L6450	DC	Inside	No ♦	2 Hrs	HP10000
2011-2016	F-250 SUPER DUTY (2WD/4WD) RATED UP TO 7500lbs	HP10387-X †††	L6526	DC	Inside	No ♦	2 Hrs	HP10438
2017-2022	F-250 SUPER DUTY (2WD/4WD [‡]) SRW & DRW <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401	L6537	DC	Inside	No ♦	2½ Hrs	HP10000
2017-2022	F-250 SUPER DUTY (2WD/4WD [‡]) SRW & DRW RATED UP TO 7500lbs <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401-X	L6538	DC	Inside	No ♦	2½ Hrs	HP10438
2023-2024	F-250 SUPER DUTY (2WD/4WD [‡]) SRW & DRW DIESEL ENGINES ONLY <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401	L6537	DC	Inside	No ♦	2½ Hrs	HP10000
2023-2024	F-250 SUPER DUTY (2WD/4WD [‡]) SRW & DRW DIESEL ENGINES ONLY RATED UP TO 7500lbs <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401-X	L6538	DC	Inside	No ♦	2½ Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
*	10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME			†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
**	WILL ONLY FIT WITH STOCK WHEELS AND TIRES			††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
***	FOR 'C' CHANNEL FRAMES			†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
****	FOR HYDRO FORMED FRAMES			‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪	WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION			‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
✕	VEHICLE MUST HAVE A LIFT BLOCK			♦	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ	IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120			◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
				▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

1670 Grant Ave, Blaine, WA 98230

800.663.0096 / pacbrake.com



CANADA

26688 56 Ave, Langley, BC V4W 3X5

EMAIL info@pacbrake.com

FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
FORD								
Ford F-350								
1970-1997	F-350 (2WD)	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1980-1997	F-350 (4WD) EXCEPT SUPER HD CHASSIS	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1999-2004	F-350 SUPER DUTY (2WD) 11,200 GVWR & UNDER	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
1999-2010	F-350 SUPER DUTY (2WD/4WD)	HP10070 ††	L5754	DC	Outside	Yes	3 Hrs	HP10000
2005-2010	F-350 SUPER DUTY (2WD)	HP10182 †††	L6220	DC	Inside	No ♦	4 Hrs	HP10000
2005-2010	F-350 SUPER DUTY (4WD)	HP10181 †††	L6220	DC	Inside	No ♦	4 Hrs	HP10000
2010-2016	F-350 SUPER DUTY (2WD/4WD) <i>Will not fit vehicles with factory installed 5th wheel hitch</i>	HP10070 ††	L5754	DC	Outside	Yes	3 Hrs	HP10000
2011-2016	F-350 SUPER DUTY (2WD)	HP10194 †††	L6219	DC	Inside	No ♦	4 Hrs	HP10000
2011-2016	F-350 SUPER DUTY (2WD/4WD)	HP10387 †††	L6450	DC	Inside	No ♦	2 Hrs	HP10000
2011-2016	F-350 SUPER DUTY (2WD/4WD) <small>RATED UP TO 7500lbs</small>	HP10387-X †††	L6526	DC	Inside	No ♦	2 Hrs	HP10438
2017-2022	F-350 SUPER DUTY (2WD/4WD [‡]) SRW & DRW <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401	L6537	DC	Inside	No ♦	2½ Hrs	HP10000
2017-2022	F-350 SUPER DUTY (2WD/4WD [‡]) SRW & DRW <small>RATED UP TO 7500lbs</small> <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401-X	L6538	DC	Inside	No ♦	2½ Hrs	HP10438
2023-2024	F-350 SUPER DUTY (2WD/4WD [‡]) SRW & DRW DIESEL ENGINES ONLY <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401	L6537	DC	Inside	No ♦	2½ Hrs	HP10000
2023-2024	F-350 SUPER DUTY (2WD/4WD [‡]) SRW & DRW DIESEL ENGINES ONLY <small>RATED UP TO 7500lbs</small> <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401-X	L6538	DC	Inside	No ♦	2½ Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
*	10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME			†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
**	WILL ONLY FIT WITH STOCK WHEELS AND TIRES			††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
***	FOR 'C' CHANNEL FRAMES			†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
****	FOR HYDRO FORMED FRAMES			‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪	WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION			‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
✕	VEHICLE MUST HAVE A LIFT BLOCK			♦	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ	IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120			◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
				▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230 • 800.663.0096 / pacbrake.com

26688 56 Ave, Langley, BC V4W 3X5 • EMAIL info@pacbrake.com • FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
------	------------	-------	----------------	---	-------------	--	--	--

FORD

Ford F-450

2008-2010	F-450 SUPER DUTY (2WD/4WD)	HP10187 †††	L6225	DC	Inside	No	4 Hrs	HP10000
2011-2014	F-450 SUPER DUTY (2WD)	HP10194 †††	L6219	DC	Inside	No ♦	4 Hrs	HP10000
2011-2014	F-450 SUPER DUTY (2WD/4WD)	HP10387 †††	L6450	DC	Inside	No ♦	2 Hrs	HP10000
2011-2014	F-450 SUPER DUTY (2WD/4WD) <small>RATED UP TO 7500lbs</small>	HP10387-X †††	L6526	DC	Inside	No	2 Hrs	HP10438
2015-2016	F-450 SUPER DUTY (2WD/4WD)	HP10195 †††	L6225	DC	Inside	No	3 Hrs	HP10000
2017-2022	F-450 SUPER DUTY (2WD / 4WD [‡]) SRW & DRW <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401	L6537	DC	Inside	No ♦	2½ Hrs	HP10000
2017-2022	F-450 SUPER DUTY (2WD / 4WD [‡]) SRW & DRW <small>RATED UP TO 7500lbs</small> <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401-X	L6538	DC	Inside	No ♦	2½ Hrs	HP10438
2023-2024	F-450 SUPER DUTY (2WD / 4WD [‡]) SRW & DRW <small>DIESEL ENGINES ONLY</small> <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401	L6537	DC	Inside	No ♦	2½ Hrs	HP10000
2023-2024	F-450 SUPER DUTY (2WD / 4WD [‡]) SRW & DRW <small>DIESEL ENGINES ONLY</small> <small>RATED UP TO 7500lbs</small> <i>Will not fit cab & chassis models. [‡]4WD Vehicles equipped with a rear sway bar or camper package need the 10540 retrofit kit</i>	HP10401-X	L6538	DC	Inside	No ♦	2½ Hrs	HP10438

Ford Vans / Commercial Vehicles

2015-2024	TRANSIT 150 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Transit models</i>	HP10307	L6444	DC	Inside	No	2½ Hrs	HP10000
2015-2024	TRANSIT 250 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Transit models</i>	HP10307	L6444	DC	Inside	No	2½ Hrs	HP10000
2015-2024	TRANSIT 350 (2WD/4WD) SRW VEHICLES <i>Will not fit 350HD or DRW vehicles, or E-Transit models.</i>	HP10307	L6444	DC	Inside	No	2½ Hrs	HP10000
2013-2024	TRANSIT 350HD DRW (2WD/4WD) CAB & CHASSIS / CLASS C MOTORHOME	HP10398	L6541	DC	Inside	No	2½ Hrs	HP10000
2008-2024	E-450 (2WD/4WD) CAB & CHASSIS / CLASS C MOTORHOME	HP10370	L6503	DC	Inside	No	1½ Hrs	HP10000
2012-2024	F-450 (2WD/4WD) CAB & CHASSIS	HP10324	L6459	DC	Outside	Yes	3 Hrs	HP10068
2012-2024	F-550 (2WD/4WD) CAB & CHASSIS	HP10324	L6459	DC	Outside	Yes	3 Hrs	HP10068
2012-2024	F-600 (2WD/4WD) CAB & CHASSIS	HP10324	L6459	DC	Outside	Yes	3 Hrs	HP10068
2009-2024	F-53 STRIPPED CAB & CHASSIS / CLASS A MOTORHOME <i>Will not fit models with 10886kg (24000lbs) or 11793kg (26000lbs) GVWR</i>	HP10475	L6559	DC	Outside	Yes	3 Hrs	HP10068

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
*	10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME			†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
**	WILL ONLY FIT WITH STOCK WHEELS AND TIRES			††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
***	FOR 'C' CHANNEL FRAMES			†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
****	FOR HYDRO FORMED FRAMES			‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪	WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION			‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
✕	VEHICLE MUST HAVE A LIFT BLOCK			♦	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ	IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120			◆	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
				▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230

26688 56 Ave, Langley, BC V4W 3X5

800.663.0096 / pacbrake.com

EMAIL info@pacbrake.com

FAX 604.882.2330



REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
------	------------	-------	----------------	---	-------------	--	--	--

FREIGHTLINER

2007-2014	SPRINTER 2500 (2WD)	HP10147	L6037	DC	Inside	Yes	3 Hrs	HP10000
2007-2024	SPRINTER 2500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10395 ▼	L6536	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 2500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10395-X ▼	L6536	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 3500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10395 ▼	L6536	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 3500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10395-X ▼	L6536	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 3500XD (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10391 ▼	L6527	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 3500XD (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10391-X ▼	L6527	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 4500 (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10391 ▼	L6527	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 4500 (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10391-X ▼	L6527	DC	Inside	No	2 Hrs	HP10438

MAZDA

1998-2010	MAZDA PICK-UPS (2WD/4WD) <i>Will only fit with stock wheels and tires</i>	HP10019 †	L5685	DC	Outside	Yes	3 Hrs	HP10000
-----------	---	------------------	--------------	-----------	---------	-----	-------	---------

MERCEDES

2010-2014	SPRINTER 2500 (2WD)	HP10147	L6037	DC	Inside	Yes	3 Hrs	HP10000
2007-2024	SPRINTER 2500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10395 ▼	L6536	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 2500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10395-X ▼	L6536	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 3500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10395 ▼	L6536	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 3500 (2WD/4WD) SRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10395-X ▼	L6536	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 3500XD (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10391 ▼	L6527	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 3500XD (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10391-X ▼	L6527	DC	Inside	No	2 Hrs	HP10438
2007-2024	SPRINTER 4500 (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i>	HP10391 ▼	L6527	DC	Inside	No	2 Hrs	HP10000
2007-2024	SPRINTER 4500 (2WD/4WD) DRW VEHICLES <i>Will not fit E-Sprinter models</i> RATED UP TO 7500LBS	HP10391-X ▼	L6527	DC	Inside	No	2 Hrs	HP10438

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
*	10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME			†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
**	WILL ONLY FIT WITH STOCK WHEELS AND TIRES			††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
***	FOR 'C' CHANNEL FRAMES			†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
****	FOR HYDRO FORMED FRAMES			‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪	WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION			‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
✕	VEHICLE MUST HAVE A LIFT BLOCK			◆	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ	IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120			◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
				▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230 • 800.663.0096 / pacbrake.com

26688 56 Ave, Langley, BC V4W 3X5 • EMAIL info@pacbrake.com • FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
NISSAN								
2004-2015	TITAN (2WD/4WD) <i>Will not fit PRO-4X models</i>	HP10222	L6376	DC	Inside	Yes	2 Hrs	HP10000
2016-2019	TITAN XD (2WD/4WD) XD MODELS ONLY	HP10338	L6477	DC	Inside	No	2 Hrs	HP10000
STERLING								
2007-2009	BULLET 4500 (2WD/4WD) CAB & CHASSIS	HP10121	L5934	DC	Inside	No	3 Hrs	HP10068
2007-2009	BULLET 5500 (2WD/4WD) CAB & CHASSIS	HP10121	L5934	DC	Inside	No	3 Hrs	HP10068
TOYOTA								
Toyota Tacoma ALL TOYOTA KITS REQUIRE A MINIMUM OF 5" BETWEEN THE TIRE AND FRAME AND WILL ONLY FIT WITH STOCK WHEELS AND TIRES 1995-2004. THIS DOES NOT APPLY TO 10311.								
1995-2004	TOYOTA TACOMA (4WD)	HP10191	L6270	SS	Outside	Yes	3 Hrs	HP10173
2005-2014	TOYOTA TACOMA (4WD)	HP10165	L6173	SS	Outside	No	3 Hrs	HP10199
2005-2023	TOYOTA TACOMA (4WD)	HP10311	L6449	SC	Inside	No	2½ Hrs	HP10083
2005-2023	TOYOTA TACOMA PRERUNNER (2WD)	HP10311	L6449	SC	Inside	No	2½ Hrs	HP10083
Toyota Tundra ALL TOYOTA KITS REQUIRE A MINIMUM OF 5" BETWEEN THE TIRE AND FRAME AND WILL ONLY FIT WITH STOCK WHEELS AND TIRES 1995-2004								
2001-2006	TOYOTA TUNDRA (2WD/4WD)	HP10126	L6010	SC	Outside	No	2½ Hrs	HP10083
2001-2006	TOYOTA TUNDRA (2WD/4WD) <i>Trucks in which the upper jounce bumper pad protrudes 1" below the frame</i>	HP10158	L6010	SC	Outside	No	2½ Hrs	HP10083
2007-2021	TOYOTA TUNDRA (2WD/4WD)	HP10128	L6010	SC	Outside	No	2½ Hrs	HP10083
UNIVERSAL FIT								
FABRICATORS FRONT AIR SPRING KIT LARGE AIR SPRINGS		HP10086	L5953	DC	—	—	—	HP10068

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
*	10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME			†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
**	WILL ONLY FIT WITH STOCK WHEELS AND TIRES			††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
***	FOR 'C' CHANNEL FRAMES			†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
****	FOR HYDRO FORMED FRAMES			‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪	WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION			‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
×	VEHICLE MUST HAVE A LIFT BLOCK			◆	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ	IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120			◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
				▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

1670 Grant Ave, Blaine, WA 98230

800.663.0096 / pacbrake.com



CANADA

26688 56 Ave, Langley, BC V4W 3X5

EMAIL info@pacbrake.com

FAX 604.882.2330

REV135_01.15.2024



PACBRAKE APPLICATION GUIDE

ALPHA™ AIR SUSPENSION KITS

UPDATED: January 15, 2024

YEAR	MAKE/MODEL	KIT #	INSTALL MANUAL	S	FRAME MOUNT			
------	------------	-------	----------------	---	-------------	--	--	--

AIR SUSPENSION ACCESSORIES

Additional Required Add-Ons

Axel Breather Relocation Kit <i>Must be purchased with 10002 kits for 2007-2018 RAM 3500 (2WD/4WD) CAB & CHASSIS vehicles that have a round axle tube with the breather located approximately 7" from the driver side leaf spring pack.</i>	HP10136	L5958	DC	—	—	—	—
Axel Breather Relocation Kit <i>Must be purchased with 10002 kits for 2019+ RAM 3500 (2WD/4WD) CAB & CHASSIS vehicles that have a round axle tube with the breather located approximately 7" from the driver side leaf spring pack.</i>	HP10349	L6490	DC	—	—	—	—
10401 / 10401-X RetroFit <i>Must be purchased with 10401 / 10401-X kits for 2017-2024 F-450 SUPER DUTY 4WD vehicles equipped with a rear sway bar or camper package.</i>	HP10540	L6537 / L6538	DC	—	—	—	—
(Passenger Side) Rear Height Sensor Relocation Brackets <i>Must be purchased with 10402 kits for 2021-2024 FORD F-150 4WD vehicles equipped with CCD (continuously controlled dampening). 10402 kits include driver side brackets.</i>	HP10402-RH	L6594	DC	—	—	—	—

Spacers

2" Spacers <i>Universal fit with single & double convoluted air springs only</i>	HP10152	L6100	DC/SC	—	—	—	—
4" Spacers <i>Universal fit with single & double convoluted air springs only</i>	HP10154	L6100	DC/SC	—	—	—	—
6" Spacers <i>Universal fit with single & double convoluted air springs only</i>	HP10156	L6100	DC/SC	—	—	—	—

REPLACEMENT AIR SUSPENSION SPRINGS

REPLACEMENT In-Coil Air Spring	HP10189	—	IC	—	—	—	—
REPLACEMENT In-Coil Air Spring	HP10560	—	IC	—	—	—	—
REPLACEMENT Sleeve Style Air Spring	HP10001	—	SS	—	—	—	—
REPLACEMENT Sleeve Style Air Spring	HP10173	—	SS	—	—	—	—
REPLACEMENT Sleeve Style Air Spring	HP10199	—	SS	—	—	—	—
REPLACEMENT Single Convoluted Air Spring	HP10083	—	SC	—	—	—	—
REPLACEMENT Double Convoluted Air Spring	HP10000	—	DC	—	—	—	—
REPLACEMENT Large Double Convoluted Air Spring	HP10068	—	DC	—	—	—	—
REPLACEMENT Extreme Duty Large Double Convoluted Air Spring	HP10438	—	DC	—	—	—	—

PLEASE NOTE: Kits are designed to fit stock vehicles. For modified vehicles we recommend checking the fitment. Rated up to 5000lbs unless otherwise stated.

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL
*	10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME			†	10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)		
**	WILL ONLY FIT WITH STOCK WHEELS AND TIRES			††	10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH		
***	FOR 'C' CHANNEL FRAMES			†††	FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS		
****	FOR HYDRO FORMED FRAMES			‡	10002 KITS FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES		
▪	WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION			‡‡	10089 KITS WILL NOT FIT WITH 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES		
×	VEHICLE MUST HAVE A LIFT BLOCK			◆	DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH		
Δ	IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT 10120			◇	SEE MANUAL OR CALL FOR SPECIFIC SUB-MODEL APPLICATIONS		
				▼	WILL NOT FIT MODELS WITH RIDE HEIGHT SENSORS		



PACBRAKE

USA

CANADA

1670 Grant Ave, Blaine, WA 98230

26688 56 Ave, Langley, BC V4W 3X5

800.663.0096 / pacbrake.com

EMAIL info@pacbrake.com

FAX 604.882.2330



REV135_01.15.2024