

Installation Manual

POWERHALT
AIR INTAKE EMERGENCY SHUT-OFF VALVES by PACBRAKE

PH1



PH5



PH1 / PH5 ADD-ON HANDLE INSTALLATION

L6644 • ECN 1-3092

800.663.0096

www.powerhalt.com



ATTENTION

Prior to installation, read through all installation requirements.

If you cannot meet certain requirements, or are unsure of your system, contact your dealer or PowerHalt representative and we can work with you to overcome your installation constraints and challenges.

A PowerHalt Technical Representative can be reached Monday-Friday 6:00-4:30 (PST) at 800.663.0096

1. Install supplied No. 2 twist drill into a cordless drill chuck with 1.25" protruding from the chuck jaws
2. Hold the handle against the knob, aligning the handle to the direction indicated in the etching of the knob (the flow direction of the valve)
3. Use one hole in the handle as a guide for the drill, drill fully until chuck contacts handle surface to achieve the correct depth
4. Install the thread forming screw to secure the handle using a 3/8" wrench or socket driver
5. Drill the second hole fully in the same way, and install the second thread-forming screw
6. Use compressed air to clear chips from around the rotating mechanism



CUSTOMER SERVICE HOURS

MONDAY TO FRIDAY FROM 6:00 AM TO 4:30 PM PST

BUSINESS HOURS OF OPERATION

MONDAY TO FRIDAY FROM 7:30 AM TO 4:00 PM PST

CORPORATE HEADQUARTERS / R&D CENTER

26688 56TH AVENUE
 LANGLEY, BRITISH COLUMBIA

Patents pending. Pacbrake is a registered trademark of Pacbrake Company. Other trademarks used herein are property of their respective holders.



POWERHALT

PowerHalt is a registered trademark of Pacbrake Co.

