

PACBRAKE'S PRESSURE REGULATED EXHAUST BRAKE

— for the Majority of Diesel Engines

PRXB exhaust brakes deliver constant backpressure throughout the entire operating RPM range for unmatched stopping power

PRXB exhaust brakes offer the highest braking power to lowest price ratio available. Pacbrake's flagship product is the unquestioned leader in the supplemental brake industry. It has changed the way people think about exhaust brakes by providing performance, safety and durability that is unmatched by any other exhaust brake on the market.

Upgrade any standard exhaust brake to a PRXB for an improved design and a longer lasting brake with significantly increased performance.

Tow & haul with complete control!

**From November 29 to December 31, 2019
you can receive a FREE AMP Air Suspension Kit
when you purchase any Automotive PRXB
Exhaust Brake Kit**

See back for complete details...

- » Severe duty & military approved
- » Decreased service brake wear
- » Compliant with latest emission regulations
- » Withstands extremely high exhaust temperatures
- » No risk of engine overpressure

PACBRAKE®

www.pacbrake.com/REBATE / 800.663.0096

WITH THE PURCHASE
OF ANY
PRXB EXHAUST BRAKE KIT
NOV 29 - DEC 31, 2019
**FREE
AIR SPRING
KIT**
CONSUMER MAIL-IN REBATE



WINTER 2019 PROMO November 29 - December 31, 2019

Purchase any PRXB EXHAUST BRAKE KIT & receive a **FREE AMP AIR SUSPENSION KIT!**



Please follow ALL below instructions in order to qualify for the FREE AMP Air Suspension Kit of your choosing.

! Please Note: The FREE AMP Air Suspension kit will be processed & fulfilled by Pacbrake Company and not through an authorized Pacbrake Dealer at the time of the original PRXB kit purchase.

In order for Pacbrake to send you a FREE AMP Air Suspension Kit, you MUST:

- ▶ Purchase a qualifying automotive PRXB Exhaust Brake Kit between November 29, 2019 and December 31, 2019.
- ▶ Be a USA or Canadian resident (this offer is only valid in the USA or Canada).
 - ▶ Limit of one FREE kit per household or address.
 - ▶ Consumer offer only.
- ▶ Submit all required documents (*listed below*) at the same time in one envelope - postmarked on or before January 15, 2020 in order for rebate to be honored.

- !** Fully completed **mail-in rebate form** (*bottom section*), including the AMP Air Suspension Kit part number that you wish to receive:
 - ▶ Application information can be found on the following pages or by visiting www.pacbrake.com/AMPguide
 - ▶ If you need assistance selecting an application please contact Pacbrake at 800.663.0096 and speak with one of our Customer Service Representatives.
- !** Your **original, dated sales receipt(s)** (*printed email receipts are acceptable*) showing the PRXB Exhaust Brake Kit purchase, including taxes (*where applicable*).
- !** Fully completed **warranty card** (*included in the envelope inside your kit*).
- !** **Original UPC** (*see example*) cut off from the PRXB Exhaust Brake Kit box.

ORIGINAL UPC EXAMPLE

The UPC code is located on the front side panel of PRXB Exhaust Brake Kit box and will have a part number, barcode and Pacbrake logo. Please cut out and send the entire label as shown to the right. Do not send the shipping label – this will not be accepted. Copies of the UPC code will also not be accepted.



NOVEMBER 29 - DECEMBER 31, 2019
BUY A PRXB
GET A
FREE AIR SPRING KIT

MAIL TO: PACBRAKE COMPANY

USA

PO Box 1822
Blaine, WA 98231-1822
USA

CANADA

19594 96 Ave,
Surrey, BC V4N 4C3
Canada

SEND ME AN HP _____ AS MY FREE AIR SUSPENSION KIT!

PERSONAL INFO:

FIRST NAME _____ LAST NAME _____

STREET ADDRESS _____

CITY _____ STATE/PROV. _____ ZIP/POSTAL _____

EMAIL _____ PHONE (_____) _____

☐ YES! Please subscribe me to your Newsletter

VEHICLE INFO:

YEAR _____ MAKE _____ MODEL _____

///PACBRAKE

www.pacbrake.com/REBATE / 800.663.0096



TERMS & CONDITIONS - All required forms & documentation (as stated above) MUST be completed and submitted to be eligible for promotion. If a kit number is not selected one will not be shipped out to you. Offer is valid from November 29 to December 31, 2019. All required forms MUST be completed and submitted in one envelope in order to qualify for promotion/rebate. Offer valid only on Pacbrake products listed above. Offer excludes all other Pacbrake products including RV Upgrades or "Brake only" kits. Offer is subject to product availability. Offer is not transferable. No substitutions or extensions. Offer applies to end user, original customer only in Canada and the U.S. No resellers, distributors or dealers. Dealers are NOT allowed to promote their own stock and submit on customer's behalf. Offer not available for online auction listings (ie: eBay, or other). Request must be postmarked on or before January 15, 2020. No inquiries will be accepted for this promotion after January 15, 2020. Void where prohibited or restricted by law. Only one submission per purchased product per name/ household/ address. This offer is not retroactive and cannot be used in conjunction with any other offer. Please allow 6 to 8 weeks after verification for processing of a properly completed claim. Keep copies of all materials submitted; originals become the property of Pacbrake and Pacbrake may use the information provided in accordance with its privacy policy posted on its website. Pacbrake is not responsible for lost, stolen, invalid or incomplete submissions.

Air Spring Application Guide

UPDATED: November 6, 2019

MODEL	YEAR	KIT #		FRAME MOUNT			
-------	------	-------	--	-------------	---	---	---

CHEVROLET/GMC

Chevrolet/GMC SUVs

JIMMY/BLAZER (4WD)	1969-1991	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
JIMMY/BLAZER (2WD)	1973-1991	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001

Chevrolet/GMC Pickup Trucks

COLORADO/CANYON (2WD/4WD) ◇	2004-2012	HP10224 ◇	SS	Inside	No	2 Hrs	HP10001
COLORADO/CANYON (2WD/4WD) ◇	2009-2012	HP10226 ◇	SS	Inside	No	2 Hrs	HP10173
COLORADO/CANYON (2WD/4WD) Includes ZR2	2015 +	HP10339	SS	Inside	No	2 Hrs	HP10001





Chevrolet Silverado/GMC Sierra 1500

C-10 (2WD)	1973-1987	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
C-10 (2WD)	1973-1987	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
K-10 (4WD)	1973-1987	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
K-10 (4WD)	1973-1987	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
SIERRA/SILVERADO K/C 1500 Δ (2WD/4WD)	1988-1998	HP10088 *** / Δ HP10120 *** / Δ	DC	Inside	Yes	3 Hrs	HP10000D HP10001
SIERRA/SILVERADO 1500HD (2WD/4WD) HEAVY LOADS	2001-2006	HP10072 ****	DC	Inside	No	2½ Hrs	HP10000D
SIERRA/SILVERADO 1500 (2WD/4WD)	1999-2007	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
SILVERADO 1500HD (2WD/4WD)	2001-2005	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
SIERRA 1500HD (2WD/4WD)	2001-2008	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
SIERRA/SILVERADO 1500 (2WD/4WD) FOR SHORT (69.3") AND MEDIUM (78.7") TRUCK BED LENGTHS WILL NOT FIT IF VEHICLE IS EQUIPPED WITH MAGNERIDE	2007-2018	HP10216	DC	Inside	No ♦	3 Hrs	HP10000D
SIERRA/SILVERADO 1500 (2WD/4WD) FOR SHORT (69.3") AND MEDIUM (78.7") TRUCK BED LENGTHS	2007-2018	HP10144	SS	Outside	No	2 Hrs	HP10001
SIERRA/SILVERADO 1500 (2WD/4WD) FOR LONG (97.8") TRUCK BED LENGTHS	2007-2018	HP10178	SS	Outside	No	2 Hrs	HP10001
SIERRA LIMITED/SILVERADO LD 1500 (2WD/4WD)	2007-2018	HP10216	DC	Outside	No ♦	2 Hrs	HP10000D

Chevrolet Silverado/GMC Sierra 2500

C-20 (2WD)	1973-1987	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
C-20 (2WD)	1973-1987	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
K-20 (4WD)	1973-1987	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
SIERRA/SILVERADO K/C 2500 Δ (2WD/4WD)	1988-1998	HP10088 *** / Δ HP10120 *** / Δ	DC	Inside	Yes	3 Hrs	HP10000D HP10001
SIERRA/SILVERADO 2500 Δ (2WD/4WD) (DRUM BRAKES ONLY)	1999-2000	HP10088 *** / Δ HP10120 *** / Δ	DC	Inside	Yes	3 Hrs	HP10000D HP10001
SIERRA/SILVERADO 2500HD (2WD/4WD)	2001-2010	HP10005	DC	Inside	No	2 Hrs	HP10000D

Not for commercial cab and chassis

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL

* THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME

** WILL ONLY FIT WITH STOCK WHEELS AND TIRES

*** FOR 'C' CHANNEL FRAMES

**** FOR HYDRO FORMED FRAMES

▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION

◇ SEE MANUAL (LINKED TO KIT#) OR CONTACT PACBRAKE FOR SPECIFIC SUB-MODEL APPLICATIONS

Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT HP10120

† HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)

†† HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH

††† FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS

‡ THE HP10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES

‡‡ THE HP10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES

♦ DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH

Air Spring Application Guide

UPDATED: November 6, 2019

MODEL	YEAR	KIT #		FRAME MOUNT			
-------	------	-------	--	-------------	---	---	---

CHEVROLET/GMC

Chevrolet Silverado/GMC Sierra 2500 (continued)

SIERRA/SILVERADO 2500HD (2WD/4WD) <small>Not for commercial cab and chassis</small>	2011-2019	HP10171 †††	DC	Inside	No ♦	2½ Hrs	HP10000D
---	-----------	--------------------	-----------	--------	------	--------	----------

Chevrolet Silverado/GMC Sierra 3500

C-30 (2WD)	1973-1987	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
C-30 (2WD)	1973-1987	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
K-30 (4WD)	1973-1987	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
SIERRA/SILVERADO K/C 3500 Δ (2WD/4WD)	1988-2000	HP10088 *** / Δ HP10120 *** / Δ	DC	Inside	Yes	3 Hrs	HP10000D HP10001
SIERRA/SILVERADO 3500 (2WD/4WD) <small>Not for commercial cab and chassis</small>	2001-2010	HP10005	DC	Inside	No	2 Hrs	HP10000D
SIERRA/SILVERADO 3500HD (2WD/4WD) <small>Not for commercial cab and chassis</small>	2011-2019	HP10171 †††	DC	Inside	No ♦	2½ Hrs	HP10000D

Chevrolet/GMC Motorhomes (Class C Vans)

CLASS C MOTORHOME G3500 (2WD) <small>Dual rear wheels</small>	2013-2015	HP10227	SC	Inside	No	2 Hrs	HP10083
CLASS C MOTORHOME G4500 (2WD) <small>Dual rear wheels</small>	2013-2015	HP10227	SC	Inside	No	2 Hrs	HP10083

DODGE/RAM

Dodge SUVs





RAM CHARGER (2WD/4WD)	1974-1993	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
------------------------------	-----------	------------------	-----------	---------	-----	--------	---------

Dodge Pickup Trucks

DAKOTA (4WD)	1987-2004	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
DAKOTA (2WD/4WD) ♦	2005-2011	HP10220 ♦	SS	Outside	Yes	2½ Hrs	HP10001
DAKOTA RT (2WD)	2000-2001	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
W-100 (2WD/4WD)	1969-1993	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
W-100 (2WD/4WD) HEAVY LOADS	1969-1993	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
D-150, W-150 (2WD/4WD)	1969-1993	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
D-150, W-150 (2WD/4WD) HEAVY LOADS	1969-1993	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
D-250, W-250 (2WD/4WD)	1969-1993	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
D-350, W-350 (2WD/4WD)	1969-1993	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D

Ram 1500

RAM 1500 (2WD/4WD)	1994-2001	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
RAM 1500 (2WD/4WD) INNER COIL AIR SPRING	2009-2018	HP10188	IC	N/A	No	2 Hrs	HP10189
RAM 1500 (2WD) *	2019	HP10337	SC	N/A	No	2 Hrs	HP10083

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL

* THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME

** WILL ONLY FIT WITH STOCK WHEELS AND TIRES

*** FOR 'C' CHANNEL FRAMES

**** FOR HYDRO FORMED FRAMES

▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION

♦ SEE MANUAL (LINKED TO KIT#) OR CONTACT PACBRAKE FOR SPECIFIC SUB-MODEL APPLICATIONS

Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT HP10120

† HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)

†† HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH

††† FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS

‡ THE HP10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES

‡‡ THE HP10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES

♦ DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH

Air Spring Application Guide

UPDATED: November 6, 2019

MODEL	YEAR	KIT #		FRAME MOUNT			
-------	------	-------	--	-------------	---	---	---

DODGE/RAM

Ram 1500 (continued)

RAM 1500 (4WD) FOR 2WD CALL 800.663.0096 FOR ASSISTANCE	2009-2018	HP10207	DC	N/A	Yes	4 Hrs	HP10000D
RAM 1500 (4WD) *	2019	HP10336	DC	N/A	No	2 Hrs	HP10000D
RAM 1500 Classic (4WD) FOR 2WD CALL 800.663.0096	2019	HP10207	DC	N/A	Yes	4 Hrs	HP10000D
RAM 1500 (2WD) HEAVY LOADS	1994-2001	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
RAM 1500 (2WD / 4WD) HEAVY LOADS	2002-2008	HP10071	DC	Inside	No	2½ Hrs	HP10000D
RAM MEGA CAB 1500 (2WD)	2006-2008	HP10089 ‡	SC	Inside	No	2 Hrs	HP10083
RAM MEGA CAB 1500 (4WD)	2006-2008	HP10002 ‡	DC	Inside	No	2 Hrs	HP10000D

Ram 2500





RAM 2500 (2WD / 4WD)	1994-2002	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
RAM 2500 (4WD)	2003-2013	HP10002 ‡	DC	Inside	No	2 Hrs	HP10000D
RAM 2500 (2WD)	2003-2013	HP10089 ‡	SC	Inside	No	2 Hrs	HP10083
RAM MEGA CAB 2500 (4WD)	2006-2008	HP10002 ‡	DC	Inside	No	2 Hrs	HP10000D
RAM MEGA CAB 2500 (2WD)	2006-2008	HP10089 ‡	SC	Inside	No	2 Hrs	HP10083
RAM 2500 (2WD / 4WD)	2014-2019	HP10206	DC	N/A	No	2 Hrs	HP10000D

Ram 3500

RAM 3500 (2WD / 4WD)	1994-2002	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
RAM 3500 (4WD)	2003-2019	HP10002 ‡	DC	Inside	No	2 Hrs	HP10000D
RAM 3500 (2WD)	2003-2019	HP10089 ‡	SC	Inside	No	2 Hrs	HP10083
RAM MEGA CAB 3500 (4WD)	2006-2019	HP10002 ‡	DC	Inside	No	2 Hrs	HP10000D
RAM MEGA CAB 3500 (2WD)	2006-2019	HP10089 ‡	SC	Inside	No	2 Hrs	HP10083
RAM 3500 (2WD / 4WD) CHASSIS CAB <small>The HP10136 must be purchased for vehicles that have a round axle tube with the breather located approximately 7" from the spring pack.</small>	2006-2018	HP10002 ‡ & HP10136	DC	Inside	No	2 Hrs	HP10000D
RAM 3500 (2WD / 4WD) CHASSIS CAB <small>The HP10349 must be purchased for vehicles that have a round axle tube with the breather located approximately 7" from the spring pack.</small>	2019	HP10002 ‡ & HP10349	DC	Inside	No	2 Hrs	HP10000D

Dodge Vans/Commercial Vehicles

RAM 4500 (2WD / 4WD) CHASSIS CAB	2007-2009	HP10121	DC	Inside	No	3 Hrs	HP10068
RAM 4500 (2WD / 4WD) CHASSIS CAB	2010-2019	HP10321	DC	Inside	No	2 Hrs	HP10068
RAM 5500 (2WD / 4WD) CHASSIS CAB	2007-2009	HP10121	DC	Inside	No	3 Hrs	HP10068
RAM 5500 (2WD / 4WD) CHASSIS CAB	2010-2019	HP10321	DC	Inside	No	2 Hrs	HP10068
SPRINTER 2500 (2WD)	2007-2009	HP10147	DC	Inside	Yes	2½ Hrs	HP10000D

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL

* THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME

** WILL ONLY FIT WITH STOCK WHEELS AND TIRES

*** FOR 'C' CHANNEL FRAMES

**** FOR HYDRO FORMED FRAMES

▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION

◆ SEE MANUAL (LINKED TO KIT#) OR CONTACT PACBRAKE FOR SPECIFIC SUB-MODEL APPLICATIONS

Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT HP10120

† HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)

‡ HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH

‡‡ FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS

‡ THE HP10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES

‡‡ THE HP10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES

◆ DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH

Air Spring Application Guide

UPDATED: November 6, 2019

MODEL	YEAR	KIT #		FRAME MOUNT			
-------	------	-------	--	-------------	---	---	---

FORD

Ford SUVs

BRONCO (4WD)	1980-1996	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
BRONCO II (4WD)	1983-1990	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001

Ford Pickup Trucks





RANGER ** (2WD / 4WD)	1998-2010	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-100 (4WD) HEAVY LOADS	1966-1996	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-100 (4WD) LIGHT LOADS	1966-1996	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
F-100 (2WD) HEAVY LOADS	1968-1996	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-100 (2WD) LIGHT LOADS	1968-1996	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001

Ford F-150

F-150 (4WD) HEAVY LOADS	1966-1996	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-150 (2WD) HEAVY LOADS	1968-1996	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-150 (2WD) LIGHT LOADS	1968-1996	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
F-150 (2WD / 4WD) INCLUDING HERITAGE	1997-2003	HP10033 *	SS	Outside	Yes	2½ Hrs	HP10001
F-150 (2WD / 4WD) HEAVY LOADS <i>Will not fit fx2</i>	2004-2008	HP10004	DC	Outside	No	2 Hrs	HP10000D
F-150 (2WD / 4WD) EXCLUDES HERITAGE	2004-2009	HP10153	SS	Outside	No	2½ Hrs	HP10173
F-150 (2WD / 4WD) EXCLUDES HERITAGE & F-150 RAPTOR <i>Will not fit newer style, aluminum body trucks</i>	2010-2014	HP10155	SS	Outside	No	2½ Hrs	HP10001
F-150 (4WD)	2004-2014	HP10212	DC	Inside	No	2½ Hrs	HP10000D
F-150 (4WD)	2015-2019	HP10215	SC	Inside	No	2½ Hrs	HP10083
TRANSIT 150 (2WD)	2015-2019	HP10307	DC	Inside	No	2½ Hrs	HP10000D

Ford F-250

F-250 (2WD) UNDER 7500 GVWR	1969-1979	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-250 (2WD)	1980-1996	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-250 (4WD) '97 HEAVY DUTY OVER 8600 GVWR	1980-1997	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-250 LIGHT DUTY (2WD / 4WD) UNDER 7500 GVWR	1997-1998	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-250 SUPER DUTY (2WD / 4WD)	1999-2010	HP10070 ††	DC	Outside	Yes	3 Hrs	HP10000D
F-250 SUPER DUTY (2WD)	2005-2010	HP10182 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-250 SUPER DUTY (4WD)	2005-2010	HP10181 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-250 SUPER DUTY (2WD / 4WD) <i>Will not fit vehicles with factory installed 5th wheel hitch</i>	2010-2016	HP10070 ††	DC	Outside	Yes	3 Hrs	HP10000D

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL

* THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME

** WILL ONLY FIT WITH STOCK WHEELS AND TIRES

*** FOR 'C' CHANNEL FRAMES

**** FOR HYDRO FORMED FRAMES

▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION

♦ SEE MANUAL (LINKED TO KIT#) OR CONTACT PACBRAKE FOR SPECIFIC SUB-MODEL APPLICATIONS

Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT HP10120

† HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)

†† HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH

††† FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS

‡ THE HP10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES

‡‡ THE HP10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES

♦ DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH

Air Spring Application Guide

UPDATED: November 6, 2019

MODEL	YEAR	KIT #		FRAME MOUNT			
-------	------	-------	--	-------------	---	---	---

FORD

Ford F-250 (continued)

F-250 SUPER DUTY (2WD)	2011-2016	HP10194 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-250 SUPER DUTY (4WD)	2011-2016	HP10247 †††	DC	Inside	No ♦	2 Hrs	HP10068
F-250 SUPER DUTY (4WD)	2017-2019	HP10304 †††	DC	Inside	Yes	2½ Hrs	HP10000D
TRANSIT 250 (2WD)	2015-2019	HP10307	DC	Inside	No	2½ Hrs	HP10000D

Ford F-350

F-350 (2WD)	1970-1997	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-350 (4WD) EXCEPT SUPER HD CHASSIS	1980-1997	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-350 SUPER DUTY (2WD) 11,200 GVWR & UNDER	1999-2004	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
F-350 SUPER DUTY (2WD/4WD)	1999-2010	HP10070 ††	DC	Outside	Yes	3 Hrs	HP10000D
F-350 SUPER DUTY (2WD)	2005-2010	HP10182 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-350 SUPER DUTY (4WD)	2005-2010	HP10181 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-350 SUPER DUTY (2WD/4WD) <i>Will not fit vehicles with factory installed 5th wheel hitch</i>	2010-2016	HP10070 ††	DC	Outside	Yes	3 Hrs	HP10000D
F-350 SUPER DUTY (2WD)	2011-2016	HP10194 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-350 SUPER DUTY (4WD)	2011-2016	HP10247 †††	DC	Inside	No ♦	2 Hrs	HP10068
F-350 SUPER DUTY (4WD)	2017-2019	HP10304 †††	DC	Inside	Yes	2½ Hrs	HP10000D
TRANSIT 350 (2WD) <i>Will not fit 350HD or DRW vehicles</i>	2015-2019	HP10307	DC	Inside	No	2½ Hrs	HP10000D

Ford F-450







F-450 SUPER DUTY (2WD)	2011-2014	HP10194 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-450 SUPER DUTY (4WD)	2011-2014	HP10193 †††	DC	Inside	No ♦	4 Hrs	HP10000D
F-450 SUPER DUTY (2WD/4WD)	2008-2010	HP10187 †††	DC	Inside	No	4 Hrs	HP10000D
F-450 SUPER DUTY (2WD/4WD)	2015-2016	HP10195 †††	DC	Inside	No	3 Hrs	HP10000D
F-450 SUPER DUTY (4WD)	2017-2019	HP10304 †††	DC	Inside	Yes	2½ Hrs	HP10000D
F-450 SUPER DUTY (2WD/4WD) COMMERCIAL CAB & CHASSIS	2012-2019	HP10324	DC	Outside	Yes	3 Hrs	HP10068

Ford F-550

F-550 SUPER DUTY (2WD/4WD) COMMERCIAL CAB & CHASSIS	2012-2019	HP10324	DC	Outside	Yes	3 Hrs	HP10068
--	-----------	---------	----	---------	-----	-------	---------

FREIGHTLINER

SPRINTER, 2500 (2WD)	2007-2014	HP10147	DC	Inside	Yes	3 Hrs	HP10000D
----------------------	-----------	---------	----	--------	-----	-------	----------

 REPLACEMENT AIR SPRING	 AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	 SLEEVE STYLE
 VEHICLE MODIFICATION REQUIRED	 SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	 IN-COIL

* THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME

** WILL ONLY FIT WITH STOCK WHEELS AND TIRES

*** FOR 'C' CHANNEL FRAMES

**** FOR HYDRO FORMED FRAMES

▪ WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION

♦ SEE MANUAL (LINKED TO KIT#) OR CONTACT PACBRAKE FOR SPECIFIC SUB-MODEL APPLICATIONS

Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT HP10120

† HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)

†† HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH

††† FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS





‡ THE HP10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES





‡‡ THE HP10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES

♦ DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH

Air Spring Application Guide

UPDATED: November 6, 2019

MODEL	YEAR	KIT #		FRAME MOUNT			
MAZDA							
MAZDA PICK-UPS (2WD / 4WD) <i>Will only fit with stock wheels and tires</i>	1998-2010	HP10019 †	DC	Outside	Yes	3 Hrs	HP10000D
MERCEDES							
SPRINTER, 2500 (2WD)	2010-2014	HP10147	DC	Inside	Yes	3 Hrs	HP10000D
NISSAN							
TITAN (2WD / 4WD)	2004-2015	HP10222	DC	Inside	Yes	2 Hrs	HP10000D
TITAN XD (2WD / 4WD) <i>XD models only COMING SOON!</i>	2016+	HP10338	DC	Inside	No	2 Hrs	HP10000D
STERLING							
BULLET 4500, BULLET 5500 (2WD / 4WD) CHASSIS CAB	2007-2009	HP10121	DC	Inside	No	3 Hrs	HP10068
TOYOTA							
<i>Toyota Tacoma</i> ALL TOYOTA KITS REQUIRE A MINIMUM OF 5" BETWEEN THE TIRE AND FRAME AND WILL ONLY FIT WITH STOCK WHEELS AND TIRES 1995-2004. THIS DOES NOT APPLY TO HP10311.							
TOYOTA TACOMA (4WD)	1995-2004	HP10191	SS	Outside	Yes	3 Hrs	HP10173
TOYOTA TACOMA (4WD)	2005-2014	HP10165	SS	Outside	No	3 Hrs	HP10199
TOYOTA TACOMA (4WD)	2005-2019	HP10311	SC	Inside	No	2½ Hrs	HP10083
TOYOTA TACOMA PRERUNNER (2WD)	2005-2019	HP10311	SC	Inside	No	2½ Hrs	HP10083
TOYOTA TACOMA (4WD)	2005-2019	HP10328	SS	Outside	No	3 Hrs	HP10001
TOYOTA TACOMA PRERUNNER (2WD)	2005-2019	HP10328	SS	Outside	No	3 Hrs	HP10001
<i>Toyota Tundra</i> ALL TOYOTA KITS REQUIRE A MINIMUM OF 5" BETWEEN THE TIRE AND FRAME AND WILL ONLY FIT WITH STOCK WHEELS AND TIRES 1995-2004							
TOYOTA TUNDRA (2WD / 4WD)	2001-2006	HP10126	SC	Outside	No	2½ Hrs	HP10083
TOYOTA TUNDRA (2WD / 4WD) <i>Trucks in which the upper jounce bumper pad protrudes 1" below the frame</i>	2001-2006	HP10158	SC	Outside	No	2½ Hrs	HP10083
TOYOTA TUNDRA (2WD / 4WD)	2007-2019	HP10128	SC	Outside	No	2½ Hrs	HP10083
UNIVERSAL FIT							
FABRICATORS REAR AIR SPRING KIT <small>SMALL AIR SPRINGS</small>		HP10130	DC	N/A	N/A	N/A	HP10000D
FABRICATORS FRONT AIR SPRING KIT <small>LARGE AIR SPRINGS</small>		HP10086	DC	N/A	N/A	N/A	HP10068
AIR SUSPENSION SPACERS							
2" Spacers <i>Universal fit with single & double convoluted air springs only</i>		HP10152	DC / SC	N/A	N/A	N/A	N/A
4" Spacers <i>Universal fit with single & double convoluted air springs only</i>		HP10154	DC / SC	N/A	N/A	N/A	N/A
6" Spacers <i>Universal fit with single & double convoluted air springs only</i>		HP10156	DC / SC	N/A	N/A	N/A	N/A

	REPLACEMENT AIR SPRING		AIR SPRING STYLE	DC	DOUBLE CONVOLUTED	SS	SLEEVE STYLE
	VEHICLE MODIFICATION REQUIRED		SUGGESTED INSTALLATION TIME	SC	SINGLE CONVOLUTED	IC	IN-COIL

- * THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME
- ** WILL ONLY FIT WITH STOCK WHEELS AND TIRES
- *** FOR 'C' CHANNEL FRAMES
- **** FOR HYDRO FORMED FRAMES
 - WILL NOT FIT MODELS WITH FACTORY AIR SUSPENSION
- ◆ SEE MANUAL (LINKED TO KIT#) OR CONTACT PACBRAKE FOR SPECIFIC SUB-MODEL APPLICATIONS
- Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT HP10120

- † HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)
- †† HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH
- ††† FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS
- ‡ THE HP10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES
- ‡‡ THE HP10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES
- ◆ DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH