

CAUTION:

The slave piston screw torque is critical to the operation of the engine brake. Do not exceed 25 lbs ft (35N•m) Excessive torque will cause failure of the screw.

To prevent field failures, please affix these decals to the valve covers.

Warranty claims submitted for broken screws due to over torque will be denied.



Canada: 19594 - 96 Ave.,
Surrey, BC V4N 4C3

USA: P.O. Box 1822, 250 H St,
Blaine, WA 98231-1822

Phone: 800-663-0096

Fax: 604-882-9278

E-mail: info@pacbrake.com

Internet: www.pacbrake.com

Pacbrake is a registered trademark of Pacbrake Company. Other trademarks used herein are property of their respective holders. Printed in Canada

PACBRAKE[®]
ENGINE & EXHAUST BRAKES

L5396.271204